



91082

HEX KEYS & WRENCHES

Material

Aluminium

Technical Notes

Front loading collet stop:
1. Cut stop to desired length.

2. Insert stop into collet slots, tighten, face off and deburr.
3. Remove and insert machined end into collet. Face off to desired length and deburr.

4. Seat into collet and clamp workpiece. Once seated the collet need not be removed for adjustment.

Self-centering and re-usable.

Order No.	Collet size	l_1	Weight g
91082.W0020	5C	610	168